

PORTABLE AND RECHARGEABLE BLENDER USER GUIDE



Designed for everyday wellness, convenience, and fresh blended nutrition on the go.

Thank you for choosing your Mannatech Portable and Rechargeable Blender. This rechargeable blender makes it easier to prepare fresh smoothies, shakes, and blended beverages wherever your day takes you. Please read this guide carefully before using your blender.

MANNATECH®

PRODUCT SPECIFICATIONS

Item	Specification
Capacity	380 mL
Cup Lid Material	Food-grade PP
Cup Body Material	Food-grade PC/PS
Base Material	Food-grade ABS
Blade Material	304 Stainless Steel
Motor Specification	DC 3.6V
Motor Speed	No load: 22,000 RPM +/- 15%; Load: 15,000 RPM +/- 15%
Working Current	10-12A
Battery	3.7V / 2000mAh
Product Size	80 x 80 x 235 mm

BEFORE FIRST USE

1. Charge the unit fully before using it for the first time. A full charge takes approximately 3 hours.
2. Wash the cup body, lid, and grated filter top before first use.
3. Wipe the base with a clean, damp cloth. Do not submerge the base in water.
4. Make sure the base is securely tightened before each use. A loose base may cause leakage during blending.
5. To turn the blender on, quickly press the power button twice. To turn it off, press the power button once.
6. Review all safety instructions before operating the blender.

BUILT-IN FILTER FEATURE

Your Mannatech Portable and Rechargeable Blender includes a grated filter top located beneath the lid. This feature can help separate pulp or larger blended particles when pouring your beverage into another glass or cup.

This is especially helpful when blending soft fruits or vegetables and you prefer a smoother drinking experience. For beverages where you want to keep the blended fiber and pulp, you may drink directly from the blender as preferred.

SAFETY AND CARE INSTRUCTIONS

1. This product is powered by a rechargeable battery and DC motor. Use only with a compatible charging cable and power source.
2. Before operating, make sure the cup body and base are securely tightened. The blender should not operate unless properly assembled, and a loose base may cause leakage.
3. Keep hands, utensils, and other objects away from the blade area.
4. Do not operate continuously for an extended period. The maximum single blending cycle is approximately 90 seconds. Allow the product to rest between cycles to help protect the motor and support long-term performance.
5. If fruit pieces are too large or the blade becomes blocked, the motor may stop automatically as part of the product protection function. Turn off the unit, reduce the size or amount of ingredients, and restart.

- 6. Do not use liquids hotter than 50°C / 122°F. High temperatures may cause deformation or product damage.
- 7. Do not place the product in a microwave, dishwasher, oven, sterilizing cabinet, or other high-temperature appliance.
- 8. Do not immerse the base in water or rinse it directly under running water. Water entering the base may damage the electronic components.
- 9. Do not use steel wool, abrasive cleaners, corrosive liquids, or harsh cleaning agents.
- 10. This product is intended for blending soft fruits, liquids, and suitable shake ingredients only. Do not use it to grind meat, nuts, beans, ice, or other hard foods.
- 11. Keep the product out of reach of children. Children should not use or play with this product.
- 12. This product is intended for household or personal use only. If the product malfunctions, do not attempt to disassemble or repair it yourself. Contact customer service for assistance.

HOW TO USE

- 1. Wash fruit or vegetables thoroughly and cut them into small pieces, approximately 1.5 cm x 1.5 cm. Remove thick peels, hard skins, pits, seeds, and shells before blending.
- 2. Add fruit, vegetables, or suitable shake ingredients to the cup. For best results, fill the cup with solid ingredients to approximately 60% of its capacity.
- 3. Add water, milk, juice, or another suitable liquid. Do not fill the cup beyond approximately 80% of its total capacity.
- 4. Securely attach the base to the cup body. Make sure the base is fully tightened before blending to help prevent leakage.
- 5. Turn the blender upside down before starting.
- 6. Quickly press the power button twice to begin blending.
- 7. Once the blades begin rotating, turn the blender upright and gently shake during blending to help ingredients mix evenly.
- 8. For soft fruits such as oranges, bananas, or strawberries, blend for approximately 30 seconds to 1 minute.

- 9. For firmer fruits or vegetables, blend for approximately 1 to 1.5 minutes.
- 10. When blending is complete, press the power button once to turn the product off.
- 11. Carefully open the lid. To reduce pulp in your drink, pour the blended beverage through the grated filter top into another glass or cup.
- 12. If additional pulp or residue remains, strain again if desired.

BLENDING TIPS FOR BEST RESULTS

- 1. Always add liquid before blending. This helps ingredients move freely and supports a smoother blend.
- 2. Cut fruit, vegetables, and other ingredients into small, even pieces.
- 3. Do not overfill the cup. Leave enough space for ingredients to circulate.
- 4. Always confirm the base is securely tightened before blending to help avoid leaks.
- 5. Gently shake the blender while blending to help improve consistency.
- 6. For Mannatech shakes or powdered products, add liquid first, then powder, then any soft fruit or additional ingredients.
- 7. Use the grated filter top when pouring into another glass if you prefer less pulp in your finished beverage.
- 8. Clean the blender promptly after each use to help maintain freshness and performance.

CLEANING INSTRUCTIONS

- 1. Clean the blender immediately after each use.
- 2. Add clean water to the cup and briefly run the blender to help loosen residue.
- 3. Use a cleaning brush or soft sponge to clean the cup body, lid, grated filter top, and blade area carefully.
- 4. Wipe the base with a damp cloth only. Do not submerge the base in water.
- 5. Dry all parts thoroughly before storing.
- 6. Store in a cool, dry place away from direct sunlight and heat.

TROUBLESHOOTING GUIDE

Issue	Possible Cause	Recommended Action
Blender does not start	Power button may not have been activated correctly	Quickly press the power button twice to turn the blender on
Blender does not start	Battery may be low	Charge the product fully before use
Blender does not start	Cup body or base may not be tightened properly	Reassemble and tighten securely
Red indicator light flashes	Ingredients may be too large or blade may be blocked	Turn off the product, reduce ingredient size, and restart
Product stops during use	Motor protection function may have activated	Allow the product to rest, then restart
Blend is uneven	Not enough liquid or ingredients are too large	Add more liquid and cut ingredients smaller
Product leaks	Base may not be tightened securely	Remove and reattach the base, making sure it is fully tightened before blending
Product leaks	Sealing ring may be misplaced	Check that the sealing ring is properly positioned before use
Pulp remains in beverage	Grated filter top may not have been used when pouring	Pour the beverage through the grated filter top into another glass or cup
Product will not turn off	Power button may not have been pressed	Press the power button once to stop blending
Product will not charge	Charging cable or adapter may not be connected properly	Check the cable, adapter, and charging port

IMPORTANT NOTICE

The Mannatech Portable and Rechargeable Blender is designed for personal blending of soft fruits, liquids, vegetables, and suitable shake ingredients. Use only as directed. Improper use, unauthorized disassembly, or exposure of the base to water may cause product damage and may impact warranty or support eligibility. For questions or assistance, please contact Mannatech Customer Care.